


Fig. 1

1/9



SYSTEM POWER SUPPLY




Fig. 2




Fig. 4A




Fig. 4B

PREAMBLE	CBS	HUB CONTROL	DATA	ICOM	LEFT AUDIO 1	RIGHT AUDIO 1	LEFT AUDIO 2	RIGHT AUDIO 2	LEFT AUDIO 3	RIGHT AUDIO 3	LEFT AUDIO 4	RIGHT AUDIO 4
AAAAABh	CBS	HC7... HC0	D7... D0	I7... I0	A1L17... A1L0	A1R17... A1R0	A1L17... A2L0	A2R17... A2R0	A3L17... A3L0	A3R17... A3R0	A4L17... A4L0	A4R17... A4R0




Fig. 5

Fig. 6

5/9

MEDIATOO INITIALIZATION PROCESS





Fig. 7a

CONTROL MESSAGE TRANSMISSION



PREAMBLE	DESTINATION ADDRESS	SOURCE ADDRESS	NUMBER OF BYTES IN PAYLOAD	PAYLOAD	CHECKSUM
10 BYTES	1 BYTE	1 BYTE	2 BYTES	0-65KBYTES	2 BYTES

Fig. 76

CONTROL MESSAGE RECEPTION




Fig. 8



Fig. 10

8/9





Fig. 11



9/9

Fig. 12

